

INTEGRITY 3 PHASE NPT 10.0 - 30.0 KVA SEISMIC ANCHORAGE UPPER FLOOR

BOLT TORQUE SPEC: 3NM / 27 IN LBS

UNIT WEIGHT: 600 LBS MAX

INTEGRITY 3 PHASE SEISMIC ANCHORING INSTRUCTIONS:

I) MOVE THE UPS TO THE INSTALLATION LOCATION

2) ATTACH UPS SEISMIC ANCHORS (2X) NXT PART NUMBER 001-00021-01-FNL USING 3/8"-16 CLASS 8.8 BOLTS AND WASHERS (4X) AND TORQUE TO 27 IN LBS.
THESE BOLTS AND WASHERS ARE PROVIDED AND INSTALLED WITH SHIPPING BRACKETS OF THE UPS.


3) BOLT THE UPS TO THE FLOOR USING 3/8" GRADE 8 THREADED RODS (6X) AS DESCRIBED BELOW.

CHANGE DESCRIPTION

ENGINEER

BRO

Mar-15-23



DIMENSIONS ARE IN DECIMAL INCHES

ANGULAR: MACHINED ±0.5° BEND ± 1°

ONE PLACE DECIMAL: ±.03
TWO PLACE DECIMAL: ±.010
THREE PLACE DECIMAL: ±.005
BREAK SHARP EDGES: .01-.02R

NXT POWER PART NO. NPT 10.0 - 30.0 KVA

INITIATOR: BRO

DESCRIPTION: 10.0 - 30.0 KVA SEISMIC ANCHORAGE SPECS FINISH: NA

REVISION: A

MATERIAL: NA

SCALE: 0.100 PAGE: 3 of 9

SIZE: D

TOLERANCES

INTEGRITY 3 PHASE
NPT 10.0 - 30.0 KVA
SEISMIC ANCHORAGE
SLAB ON GRADE

BOLT TORQUE SPEC: 3NM / 27 IN LBS

UNIT WEIGHT: 600 LBS MAX

INTEGRITY 3 PHASE SEISMIC ANCHORING INSTRUCTIONS:

1) MOVE THE UPS TO THE INSTALLATION LOCATION
2) ATTACH UPS SEISMIC ANCHORS (2X) NXT PART NUMBER 001-00021-01-FNL
USING 3/8"-16 CLASS 8.8 BOLTS AND WASHERS (4X) AND TORQUE TO 27 IN LBS.
THESE BOLTS AND WASHERS ARE PROVIDED AND INSTALLED WITH SHIPPING BRACKETS OF THE UPS.
3) BOLT THE UPS TO THE FLOOR USING 3/8" GRADE 8 EXPANSION ANCHORS (6X) FOR CONCRETE AS DESCRIBED BELOW.

CHANGE DESCRIPTION

NXT POWER

MATERIAL: NA

SCALE: 0.100 PAGE: 2 of 9

SIZE: D

NXT POWER PART NO. NPT 10.0 - 30.0 KVA

INITIATOR: BRO


DESCRIPTION: 10.0 - 30.0 KVA SEISMIC ANCHORAGE SPECS FINISH: NA

REVISION: A

ENGINEER

BRO

Mar-15-23



UNLESS OTHERWISE SPECIFIED


ONE PLACE DECIMAL: ±.03

TWO PLACE DECIMAL: ±.010
THREE PLACE DECIMAL: ±.005
BREAK SHARP EDGES: .01-.02R

TOLERANCES

DIMENSIONS ARE IN DECIMAL INCHES

ANGULAR: MACHINED ±0.5° BEND ± 1°



INTEGRITY 3 PHASE NPT 40.0 - 75.0 KVA SEISMIC ANCHORAGE SLAB ON GRADE

BOLT TORQUE SPEC: 3NM / 27 IN LBS


UNIT WEIGHT: 950 LBS MAX

INTEGRITY 3 PHASE SEISMIC ANCHORING INSTRUCTIONS:

I) MOVE THE UPS TO THE INSTALLATION LOCATION

2) ATTACH UPS SEISMIC ANCHORS (2X) NXT PART NUMBER 001-00021-01-FNL USING 3/8"-16 CLASS 8.8 BOLTS AND WASHERS (4X) AND TORQUE TO 27 IN LBS.

THESE BOLTS AND WASHERS ARE PROVIDED AND INSTALLED WITH SHIPPING BRACKETS OF THE UPS. 3) BOLT THE UPS TO THE FLOOR USING 3/8" GRADE 8 EXPANSION ANCHORS (6X) FOR CONCRETE AS DESCRIBED BELOW.



NXT POWER PART NO. NPT 40.0 - 75.0 KVA

INITIATOR: BRO

DESCRIPTION: 40.0 - 75.0 KVA SEISMIC ANCHORAGE SPECS FINISH: NA

REVISION: A

MATERIAL: NA

SCALE: 0.083 PAGE: 5 of 9


SIZE: D

CHANGE DESCRIPTION

ENGINEER

BRO

Mar-15-23



DIMENSIONS ARE IN DECIMAL INCHES

ANGULAR: MACHINED ±0.5° BEND ± 1°

ONE PLACE DECIMAL: ±.03

TWO PLACE DECIMAL: ±.010
THREE PLACE DECIMAL: ±.005

BREAK SHARP EDGES: .01-.02R

TOLERANCES

INTEGRITY 3 PHASE NPT 40.0 - 75.0 KVA SEISMIC ANCHORAGE UPPER FLOOR

BOLT TORQUE SPEC: 3NM / 27 IN LBS

UNIT WEIGHT: 950 LBS MAX


INTEGRITY 3 PHASE SEISMIC ANCHORING INSTRUCTIONS:

I) MOVE THE UPS TO THE INSTALLATION LOCATION

NXT power

2) ATTACH UPS SEISMIC ANCHORS (2X) NXT PART NUMBER 001-00021-01-FNL USING 3/8"-16 CLASS 8.8 BOLTS AND WASHERS (4X) AND TORQUE TO 27 IN LBS.

THESE BOLTS AND WASHERS ARE PROVIDED AND INSTALLED WITH SHIPPING BRACKETS OF THE UPS.
3) BOLT THE UPS TO THE FLOOR USING 3/8" GRADE 8 THREADED RODS (6X) AS DESCRIBED BELOW.



INITIATOR: BRO

DESCRIPTION: 40.0 - 75.0 KVA SEISMIC ANCHORAGE SPECS FINISH: NA

REVISION: A

SIZE: D

SCALE: 0.083 PAGE: 6 of 9

ONE PLACE DECIMAL: ±.03


TWO PLACE DECIMAL: ±.010
THREE PLACE DECIMAL: ±.005

BREAK SHARP EDGES: .01-.02R

CHANGE DESCRIPTION

BRO

Mar-15-23



INTEGRITY 3 PHASE
NPT 80.0 - 150.0 KVA
SEISMIC ANCHORAGE
SLAB ON GRADE

BOLT TORQUE SPEC: 3NM / 27 IN LBS


UNIT WEIGHT: 1,900 LBS MAX

INTEGRITY 3 PHASE SEISMIC ANCHORING INSTRUCTIONS:

1) MOVE THE UPS TO THE INSTALLATION LOCATION

2) ATTACH UPS SEISMIC ANCHORS (2X) NXT PART NUMBER 001-00021-01-FNL USING 3/8"-16 CLASS 8.8 BOLTS AND WASHERS (4X) AND TORQUE TO 27 IN LBS. THESE BOLTS AND WASHERS ARE PROVIDED AND INSTALLED WITH SHIPPING BRACKETS OF THE UPS.

3) BOLT THE UPS TO THE FLOOR USING 3/8" GRADE 8 EXPANSION ANCHORS (6X) FOR CONCRETE AS DESCRIBED BELOW.



ANGULAR: MACHINED $\pm 0.5^{\circ}$ BEND $\pm 1^{\circ}$

ONE PLACE DECIMAL: ±.03

TWO PLACE DECIMAL: ±.010
THREE PLACE DECIMAL: ±.005

BREAK SHARP EDGES: .01-.02R

CHANGE DESCRIPTION

DESCRIPTION: 80.0 - 150.0 KVA SEISMIC ANCHORAGE SPEC FINISH: NA

REVISION: A

SIZE: D

INITIATOR: BRO

ENGINEER

BRO

Mar-16-23

SCALE: 0.067 PAGE: 8 of 9

INTEGRITY 3 PHASE NPT 80.0 - 150.0 KVA SEISMIC ANCHORAGE UPPER FLOOR

BOLT TORQUE SPEC: 3NM / 27 IN LBS


UNIT WEIGHT: 1,900 LBS MAX

INTEGRITY 3 PHASE SEISMIC ANCHORING INSTRUCTIONS:

I) MOVE THE UPS TO THE INSTALLATION LOCATION

2) ATTACH UPS SEISMIC ANCHORS (2X) NXT PART NUMBER 001-00021-01-FNL USING 3/8"-16 CLASS 8.8 BOLTS AND WASHERS (4X) AND TORQUE TO 27 IN LBS.

THESE BOLTS AND WASHERS ARE PROVIDED AND INSTALLED WITH SHIPPING BRACKETS OF THE UPS. 3) BOLT THE UPS TO THE FLOOR USING 3/8" GRADE 8 THREADED RODS (6X) AS DESCRIBED BELOW.



CHANGE DESCRIPTION

ENGINEER

BRO

Mar - 16 - 23

SCALE: 0.067 PAGE: 9 of 9

NXT POWER ←3/8" THREADED RODS GRADE 8 THRU FLOOR (6X) (HOLE DIAMETER NOT MORE THAN 1/16" LARGER THAN BOLT DIAMETER MAX)

> UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN DECIMAL INCHES TOLERANCES ANGULAR: MACHINED ±0.5° BEND ± 1° ONE PLACE DECIMAL: ±.03 TWO PLACE DECIMAL: ±.010
> THREE PLACE DECIMAL: ±.005

INITIATOR: BRO BREAK SHARP EDGES: .01-.02R

NXT POWER NXT POWER PART NO. NPT 80.0 - 150.0 KVA MATERIAL: NA DESCRIPTION: 80.0 - 150.0 KVA SEISMIC ANCHORAGE SPEC FINISH: NA

SIZE: D

REVISION: A